

Table of Contents

Chapter 3: MIDI Connections	3
<i>MIDI Connection Types</i>	3
<i>MIDI Designer Connections Menu</i>	3
<i>USB (Hardware) Connection</i>	4
<i>Bluetooth</i>	5
<i>Virtual MIDI (Inter App Connections)</i>	6
<i>WiFi (Network) MIDI</i>	8
<i>Connecting to Windows</i>	10
<i>Connection Troubleshooting</i>	11
<i>Recommendations</i>	11

Chapter 3: MIDI Connections

updated Dec 2023 for MD 3.0

MIDI Connection Types

In early days of MIDI, there was one connection - wired five pin DIN, with one cable for input, one for output.

Current specs define

1. DIN MiDI (hardwired, traditional five PIN DIN plus 2.5mm and 3.5mm TRS connections in three flavors, A, B, and TS)
2. USB,
3. Bluetooth,
4. Firewire, and
5. Network (labeled WiFi in MD, also called RTP)

There are also “virtual” MIDI, connections internal to a computer between separate applications.

There are adaptors that convert between interface, such as DIN-MIDI to Bluetooth dongles, USB to DIN-MIDI adapter, and studio boxes that provide multiple interfaces.

Apple's CoreMIDI means that MIDI is essentially a native language of iOS & MacOS. CoreMIDI does most of the connection work, Once configuration is correct, the connection (mostly) works. In earlier days of iOS, helper apps were necessary. There is still a role for helper apps to manage complicated configurations and automate some connections.

“On Mac OSX and iOS, Apple's CoreMIDI technology automatically handles the transfer of MIDI data between software apps (sequencers, softsynths, etc.) and external MIDI devices connected via USB (USB-MIDI), FireWire (1394-MIDI) and on a network (RTP-MIDI)” - midi.org


MIDI Designer Connections Menu

MIDI connection control is found at *MORE / Configuration / Connections*. This provides selection of

1. WiFi (Network)
2. BlueTooth (includes connect and enable connections controls)
3. MIDI Designer initiated Virtual MIDI in / out
4. Hardware and Virtual sources / destinations

The menu shows all available connections. Highlighted and checked entries are active. Tap to enable / disable selected connection.

For inputs, *Thru* option will echo MIDI input to all connected outputs.



**Studio MIDI interface inputs
DIN, USB, HST 1 & 2 enabled
HST3 to HST7 disabled
Thru enabled on DIN**

USB (Hardware) Connection

Hardware connections are implemented via USB cable (Lightning for older i-devices). Options for the connection include

- hardware (synth, drum machine, etc.), often via USB type B at hardware end
- five pin DIN midi adapter to connect to DIN MIDI network
- Audio / MIDI interface, providing multiple MIDI channels
- USB Hub, connecting to multiple MIDI devices
- Other devices, such as control surfaces, mixers, lighting controllers, etc.


While CoreMIDI should make most connections painless, there are occasional exceptions

- USB devices may require an OTG type cable.
- Lightning devices may require the Apple Camera Kit, or similar USB adapter.

If a device is not labeled USB "Class Compliant," plug it in and try anyway. Some manufacturers, such as Roland, provide USB MIDI capability while not providing full class compliance (in Roland's case, in favor of their proprietary USB drivers).

USB between Mac and iPad / iPhone

When connecting via cable from an iPad / iPhone to the Mac, the iPad / iPhone must first be enabled on the Mac in the *Audio Devices* window of *Audio/MIDI Setup* before the MIDI connections are available



Bluetooth

Bluetooth MIDI connections are configured with the same two-step routine you follow for other BT connections (audio, keyboards, etc.), with one difference. At the MD end of the connection, use MD Connections menu, not the device system BT menu.


- Enable pairing on first device
- Confirm connection on second device

With smart devices, you can initiate the connection at either end.

For MIDI dongles or hardware devices with limited display, put the device in BT pairing mode, then complete the connection in MD.


Once connected with BT, connections typically reconnect when the device is available.

Advertise MIDI service to complete connection on remote device




or

Complete connection started on remote device or reconnect to existing connection




Note: Bluetooth MIDI connections cannot be initiated from the OS Bluetooth menu, but one active will appear in that menu.



Virtual MIDI (Inter App Connections)

“Virtual” connections provide MIDI between applications internal to a computer. The connections can be initiated by the programs exchanging MIDI, a separate MIDI routing program, or by the OS.



MD virtual ports should be preferred, as MD keep alive functionality should keep these ports active when the app is in background. There may be cases where this is not possible, such as an app that only recognizes its own ports, or more flexibility in routing is desired. If virtual connections are being dropped, shift back to MD virtual ports.

Do not enable more than one path between two apps to prevent message duplication.

Virtual connection between MD and DM1 on iPad
 MD virtual connections enabled, DM1 disabled
 DM1 identifies its virtual ports as "network."



Apps may have different titles for their virtual connections. DM1 (above) uses generic "Network." In MD, we see it labeled DM1.

Mac - IAC Driver

MacOS also contains a virtual MIDI connection capability - *IAC Driver* (for inter - application communication). This is configured in *Audio-MIDI Setup*. Apple [directions](#)

If you find yourself needing this, a routing helper program may be a simpler solution.

WiFi (Network) MIDI



These instructions focus on iPhone, iPad and Mac. If you have another Wi-Fi MIDI device, we would appreciate feedback to update these instructions.

Configure Network

The MIDI Network must be configured on a Mac - does not need to be Apple silicon processor, just access to Audio MIDI setup.

1. Open *Audio-MIDI Setup*
2. Under *MIDI Studio*, open *MIDI Network Setup* (or click the globe icon)
3. In Bonjour Name, enter a unique name for the MIDI network, do NOT repeat the name of a device on the network
4. Click the box to activate Network Session 1
5. Open MIDI Designer (or another network MIDI-enabled app) on devices to be added to network
6. Devices should appear in the *Sessions and Directories* box
 1. Select desired device, click CONNECT
 2. Device should now appear in *Participants* list
 3. Repeat for other desired devices

Configure Participants

In MD *Connections* panel, you should now see the devices available on the MIDI network.


Initiating Mac

In MD on the Mac initiating the network, the connections panel will show remote devices available, plus the Bonjour name of the network. Ignore the Bonjour entry, click on a remote participant to connect. Between MD devices, you only have to connect at one end - the other will automatically highlight.

Devices other than the initiating Mac

The initiating Mac will not appear, instead select the Bonjour entry to connect to that Mac. Connect to other participants as above.

[Apple reference for Network MIDI configuration](#), or press ? in the *MIDI Network Setup* window.



Network Notes

- Once the network MIDI session is established
 - Devices can join and depart without having to connect on *Audio-MIDI Setup*
 - The initiating Mac can be shut down without impact.
 - Once stable, it seems as solid as BT connections, but it can make you crazy trying to get it initially established
- The WIFI connections panel may show an entry for the current device (self). If this is selected, then you are echoing MIDI data back to that instance of MD, a MIDI feedback loop. In most cases, this is not an issue, but occasional setups could have a problem. I don't have a reliable way to replicate this "self" entry.

- Theory - as long as a single device retains knowledge of the MIDI network, it remains available, and you do not have to restart the network on the Mac. I have powered down all devices, restarted, and reconnected just by tapping the device names in the *WIFI Connections* box. At some point, the network is lost, and you have to start at the beginning. iDevices are more robust than Macs at retaining the network.
- Network MIDI does not have separate options for input and output, joining a network enables both channels
- Network MIDI does not have Thru option (unneeded, since you can connect directly to any device on the network, not like DIN MIDI days where you would have a serial string)

Network Troubleshooting

If the MIDI network just will not connect

1. Sometimes just giving it some time after making selections will enable the connections
2. In *Audio-MIDI Setup* disconnect devices in the *Participants* box, then reconnect in the *Sessions and Directories* box
3. In *Audio-MIDI Setup* rebuild the Bonjour session
 1. Disconnect all devices
 2. Unselect the network session
 3. Reconfigure the Bonjour session
4. If that doesn't work, try [closing all apps and rebooting all devices](#)

Learn more about [Network MIDI](#).



Network MIDI feels like the early days of Bluetooth. Cranky, delays, likes to drop connections at random times, sometimes data shows up seconds late in one big chunk. But you can eventually get a stable connection that persists through device power cycles.

Connecting to Windows

Our condolences.

[Instructions](#) on getting connected to Windows with MIDI Designer

For Windows, you'll need [rtpMIDI](#) generously provided by Tobias Erichsen.



Please donate to this project if you use it! Tobias Erichsen's work is not only critical to your use of MD; it's also brilliant!

Connection Troubleshooting

If MD Connections menu shows a connection, but the target is not responding, use the MD log to verify the inbound and outbound messages. A stand alone MIDI log can also help - are messages getting to the computer, but not to MD (see some logger program recommendations below).

Some thoughts:

- Configure the target device to transmit MIDI
- Move a control that transmits, or play a note
- Does MD log show a received message?
- If not, try a stand alone MIDI monitor program? Does it show a message received?
- Do you have another device in your rig that indicates successful transmission? Another sound module to sound a note? Etc?

If you are having connection difficulty with a specific target, we recommend starting with the target device forums or support to see if other users have a similar issue and have found a solution. MD MIDI connections have proven robust over more than a decade of maturation. With the large number of unique MIDI devices available, it is difficult for us to troubleshoot individual unique configurations.

If inter-app connections are dropping, ensure you are using the MD Virtual Connections.

Recommendations

Adaptors

Just a few of hundreds available

[Yamaha MD-BT01 WIRELESS BLUETOOTH MIDI ADAPTER](#)

[IK Multimedia iRig MIDI 2](#) and others, USB to DIN MIDI

[iConnectivity](#) MIDI and combination Audio/MIDI interfaces, Audio 4c

[CME WIDI Adaptor](#) - Wireless DIN MIDI to BT

[PUC Wireless USB and DIN MIDI](#)

[Quicco BT DIN MIDI](#) - may be no longer available

Connectivity Helper Programs

This is just a sampling of some we have used. There are many other options.

Mathias Frick's [midimitt](#) - simplify MIDI connections

Audeonic's [MIDI Fire](#), which provides several useful MIDI tools, including StreamByter, in addition to routing

Secret Base Design's [Apollo MIDI over Bluetooth](#)

Snoise [MIDI Monitor](#) - MacOS MIDI Log, a good SysE Librarian is also available



MusicIO

BluePort <http://betafunk.dk/blueport>

Line 6 MIDI Mobilizer 2

From:
<https://mididesigner.com/wiki/> - **MIDI Designer Reference Manual**

Permanent link:
https://mididesigner.com/wiki/doku.php/manual:03_connections_redux?rev=1764950996

Last update: **2026/05/01 12:11**

